

## **DC510 programing**

1. Slide the sensor cover and remove it.
2. Pop the black plastic cover out of the sensor case.
3. Load the batteries based on the drawings.
4. The potentiometer reel is factory set to 0, it should remain that way until the end of programming.
5. Copy the sensor from the remote control:

Copy: (it is forbidden to cut the power before)

Press the P2 button 2X on the back of the remote control,

Then immediately after that, 1X the small black P2 button on the DC510!

The buttons must be pressed within 6 seconds! If so, the motor will indicate successful learning with a long beeping sound.

6. Now set the potentiometer to level 6. (will be pull in for medium strength)
7. Put back the black plastic cover and slide the cover back.
8. Mount the sensor on the front tube of the sun visor and we are done