

DC318 (wall radio receiver) installation




Connect the receiver to the motor and to the 230 voltage power as You see on the picture at the bottom.

Now push the UP and DOWN button on the the DC318 together at the same time and hold them for 3 seconds till the blue led starts flashing.

Now push the STOP button on the receiver and the blue led starts light. Now choose the right channel on the hand held emitter (which You would like to learn on the DC318) and push the UP button once 1x on the hand held emitter. Now You finished the proگرامing method. (all this method has to be done in 10 seconds).

Switch motor connection (4 wire)



230 voltage power connection (3 wire)

iroda:

H-1139 Budapest, Frangepán utca 79.

www.smart-home.hu | info@smart-home.hu | +36 20 287 1714

számlázási cím:

SANET-Trade Kft. | H-1139 Budapest, Petneházy utca 28.

Adószám: 14996429-2-41 | Bankszámlaszám: 10401000-50515755-88901018 K&H