

35RE10 motor programing

After we programmed the emitter to the motor we start the end limit settings.

1. Put the roller shutter on the half way.
2. Push on the emitter „P” UP „P” buttons, after each other, than the motor will mooves up and down 4 cm. The end limit setting started.
3. You push the UP button once and go to the top end limit, where You stop the motor. Than You push the STOP button for 6 seconds till the motor mooves up and down 4 cm. It means the motor learnt the UP end limit.
4. Than You push the DOWN button and go to the down end limit of the roller shutter, than stop where the end limit will be good! Than You push the STOP button for 6 seconds till the motor mooves up and down 4 cm. It means the motor learnt the DOWN end limit. Now You finished the END limit settings.

Important: You allways start with the UP end limit, and You can set the end limits only together!!!

www.smart-home.hu

iroda:

H-1139 Budapest, Frangepán utca 79.

www.smart-home.hu | info@smart-home.hu | +36 20 287 1714

számlázási cím:

SANET-Trade Kft. | H-1139 Budapest, Frangepán utca 79.

Adószám: 14996429-2-41 | Bankszámlaszám: 10401000-50515755-88901018 K&H