

Venetian blind motor end limit setting

1, Connect the motor to the 230 Voltage power.

2, Move the slats somewhere midle position.

3, Start to move the motor into the down direction, and during the movement push inside the small white button on the motor (keep pushing for 3 seconds till the button stucks and than leave it). When You reached the down end limit (what is okay for You), stop the motor and give it an UP direction. The white button jump out as You see and memorize the down limit.

4, Start to move the motor into the up direction, and during the movement push inside the small green button on the motor (keep pushing for 3 seconds till the button stucks and than leave it). When You reached the up end limit (what is okay for You), stop the motor and give it an DOWN direction. The green button jump out as You see and memorize the up limit.

Now all the end limit setting is finished! (You can adjust it any time if changes needed) www.smart-home.hu

