



BIDI motor programming

Installation: You use the black and white wire only for wall switch (that is optional)

Must have things:

Emitter learn: give the power to the motor (or push the button on the motor head till it gives a sign after 2 seconds) and now we have 10 seconds to learn. Now choose the emitter and the channel what we want to learn and push the STOP button till the motor moves (sign for learning).

Changing direction: (You need it if the motor is installed from the left side). You push the LEFT and RIGHT button on the emitter together and hold till it gives a sign (2 seconds).

Or push the button on the motor head, and keep pushing till the motor moves 2 times UP-Down (6 seconds) and release the button immediately. Now the direction is changed!

Setting the UP LIMIT: the motor is already in the limit setting mode (so only moves for pushing the emitter). Keep holding the UP button till You reach the UP limit (push STOP button once). Then to memorize this limit: You push and keep holding the UP and STOP button till the motor gives You a sign!

Setting the DOWN LIMIT: Keep holding the DOWN button till You reach the DOWN limit (push STOP button once). Then to memorize this limit: You push and keep holding the DOWN and STOP button till the motor gives You a sign! With this You finished the limit settings!

Optional things:

Setting the MIDDLE LIMIT: after setting the end limits go to the favourite position You would like to memorize. Push P2 (on the emitter back) and STOP and STOP button again. Learning finished. From now You keep holding the STOP button for 2 seconds and it goes to this 3rd position!

Copy the emitter: P2, P2 on the original emitter, and P2 on the new emitter once (in 6 seconds)

Delete the emitter: P2, STOP, P2 (You delete only that channel from the motor) all the other settings remain in the motor.

Motor rewind at obstacle: P2, DOWN, DOWN (motor signs the learning)

Obstacle detection strenght setting: P2, STOP, DOWN (motor moves 2 times). You do it again (motor moves 3 times) and You finished. Motor is not sensitive anymore. (You make P2, STOP, DOWN again...motor moves 1 time and it means the motor is extra sensitive again)

RADIO SIGN REPEATING: keep pushing the P2 button on the channel You want to repeat the radio sign.

Factory mode: (delete everything). On the motor head You push and keep pushing the white button till it moves UP-Down for 3 times (about 10 seconds all together) than release the button immediately after the 3rd moving! (The motor gives a beep sound and cleared from everything).